

Set up with videos:

Scan QR code or visit https://www.tp-link.com/support/setup-video/#wi-fi-routers



1 Connect the Hardware



- Unplug the power to turn off your modern, if any, and remove the backup battery if it has one.
- Place the router horizontally and orient the antennas vertically.



If your internet comes from an Ethernet outlet instead of a DSL / Cable / Satellite modem, connect the router's $\bf WAN$ port to it, then follow Step 3 and Step 4 to complete the hardware connection.



^{*}Images may differ from actual product

2 Set Up the Network

Method ONE: Via TP-Link Tether App

1. Download the Tether app.







Open the Tether app and log in with your TP-Link ID.

Note: If you don't have an account, create one first.

 Tap the + button in the Tether app and select Archer AX6000. Follow the steps to complete the setup and connect to the internet.



Enjoy the internet!

To enjoy a more complete service from TP-Link, bind your TP-Link ID to the router.

Method TWO: Via a Web Browser

 Connect your device to the router with an Ethernet cable or through a Wi-Fi network.

The default wireless network names (SSIDs) and password are printed on the label at the bottom of the router.




Launch a web browser, and enter
 http://tplinkwifi.net or http://192.168.0.1 in
 the address bar. Create a password to log in.
 Note! If the logn window does not appear, please refer to 01 of Need



 Follow the step-by-step instructions to set up the internet connection and register for the TP-Link Cloud service.

Enjoy the internet!

LED Explanation



Button Explanation



WPS Button

Press the WPS button for 1 second, and immediately press the WPS button on your client to start the WPS process.

Wi-Fi Button

Press and hold the Wi-Fi button for about 2 seconds to turn on or off the wireless function of your router.

Press the LED button for about 2 seconds to turn on or off the LED of your router.

Safety Information

- Safety information

 Keso the device way from water, fire, humidity or hot environments.

 Do not attempt to diseasemble, repair or modify the device. If you need service, please contacture.

 Do not use any other charges to happe or USS oakle to charge the device.

 Do not use any other charges to that those accommended.

 Do not use they observed water to the observed on the device where wireless device as end allowed.

 Appear nature in extention from the outpement and and local early accessible.

Need Help?



- Q1. What should I do if I can't access the web management page?

 8 aboot your notife and try again.
 If the computer is set to a static IR change its settings to octan an IP address automatically.
 Verify that http://tpil/nawfinet is correctly entered in the web browser. Alternatively, enter http://192.168.0.1 or http://192.168.1.1 in the web browser.
 Use another web browser and try again.
 Disable and enable the network adopter in use.
 Oz. What should I do if I can't access the internet?
- Q2. What should I do if I can't access the internet?

- Disable and enable the network adapter in use.

 2. What should I do if I can't access the Intermet?
 Power off your modem for about 5 minutes, then power it on and check the intermet.
 Check if the intermet is working normally by comeding a computer directly to the modem via an Ethernet cable. If it is not, contact your intermet service provider.
 Log in to the web management page of the route; and go to the Network Map page to check whether the intermet. IP address is valid or not. If it's valid, go to Advanced > Network > Intermet, click Advanced bestings, saled tube the Following DNS Addresses, set the primary DNS to 8.8.4. If it is not, check the hardware connection or contact your intermetservice provider.
 For cable modem users (go in to the web management page of the router, Go to Advanced > Network > Intermet > MAC. Clone, select Clone, Querter Device MAC and click SAVE. Then reboot both the modem and the router.

 3. What should I do if the router can't be found via Bluetooth in Tether (how to reset the router). The router's Bluetooth will be enabled for 30 minutes following a reset to factory defaults. There are two ways to reset the course.

 With the router powered on, use yan to press and hold the West the router of the land of the save for the land.

- router

 With the router powered on, use a pin to press and hold the Reset button on the back of the router for at least 2 seconds until the LED begins circulating blue.

 Log in to the web management page of the router Go to Advanced System > Backup & Restrice, and click FACTORY RESTORE. The router will reset and restrict automatically.

 The technical support, replacement services user guides, and other information, please with three plankings the communication please with three plankings the place place that the place thas the place that the place that the place that the place that th

@2020 TP-Link 7106509101 REV2.0.0





Quick Installation Guide

Archer AX6000

AX6000 8-Stream Wi-Fi 6 Router